

Accessory:



1. Air filter x1
2. Hard drive bracket x 2
3. Hard drive screw x 4
4. Vibration dampener x 4
5. Bracket screw x 8



(Fig. 1)



(Fig. 2)



(Fig. 3)



(Fig. 4)



(Fig. 5)

1. Place vibration dampeners onto hard drive brackets. (see Fig. 1)
2. Attach brackets screws to sides of main blower unit using 4 screws for each. (see Fig. 2)
3. Place hard drive between brackets and onto the vibration dampeners. Align hard drive such that the drive's mounting holes line up with the holes in the brackets. Secure the drive to the brackets with 2 screws on each side. (see Fig. 3)
4. To disengage the filter screen, slide to the left. (see Fig. 4)
5. Clean or replace filter if necessary. (see Fig 5)