



2-Serial/1-Parallel Port PCIe Adapter

User Manual

Model: UGT-PCE2S1P

All brand names and trademarks are properties of their respective owners

www.vantecusa.com

Contents

| | |
|-----------------------------|---|
| Features and Benefits..... | 3 |
| System Requirements | 4 |
| Package Contents..... | 4 |
| Hardware Installation | 4 |
| Driver Installation..... | 5 |

Features and Benefits

- | | |
|------------|---|
| Features | <ul style="list-style-type: none">● Compliant with PCI Express Base Specification 1.1● Supports 2 x UART serial port● Built-in 16C450/550 compatible UART● On chip 256 byte FIFOs in transmit and receive path of each serial port● Serial data transfer rate up to 230400bps● Supports Standard Parallel Port (SPP), Enhanced Parallel (EPP) & Enhanced Capability Port (ECP)● Parallel data transfer rate up to 1.5Mbps |
| Bus | <ul style="list-style-type: none">● PCI-Express x1 |
| Connectors | <ul style="list-style-type: none">● 2 x DB9 male serial connectors● 1 x DB25 female parallel connector |

System Requirements

- Windows® XP/Vista/7/8 (32/64 bit)
- PCI Express-enabled system with an available PCI Express slot

Package Contents

- 1 x 2-Serial/1-Parallel Port PCIe Adapter
- 1 x Bracket with two DB9 male serial ports
- 3 x Low profile brackets
- 1 x User Manual
- 1 x Driver CD

Hardware Installation

1. Turn off the power to your computer.
2. Unplug the power cord and remove your computer's cover.
3. Remove the screw and slot bracket from an available PCIe slot.
4. To install the card, carefully align the card's bus connector with the selected PCIe slot on the motherboard. Push the board down firmly.
5. Replace the slot bracket's holding screw to secure the card.

6. Replace the computer cover and reconnect the power cord.

Driver Installation

1. Insert the provided CD into your CD-ROM drive.
2. At the Windows Desktop, click **Start**, and then **Run**.
3. When the prompt displays

For Windows XP/Vista/7/8 32-bit – Enter

“D:\UGT-PC2S1PE\Windows\32Bit\stnsetup.exe” (where “D” is the designation of your CD drive)

For Windows XP/Vista/7/8 64-bit – Enter

“D:\UGT-PC2S1PE\Windows\64Bit\stnsetup.exe” (where “D” is the designation of your CD drive)

4. Follow the on-screen instructions to complete the installation.