

Installation Guide


NexStar *SX*

M.2 (NGFF) SSD to USB 3.0 Enclosure











4. Your M.2 SSD module may come in different length. Connect your M.2 SSD module at an angle into the interface on the Printed Circuit Board.



5. Use the washer provided, insert thru the mounting hole from the bottom up align with your module size. Push down the module and secure with the provided screw shown.



6. Insert the module back into the enclosure. Look carefully and align the guide rail shown to insert the Printed Circuit Board.



7. Mount the side cover back, align the cover with the expose USB port and the LED light mention in step 2 & 3. Secure with the two screws. The unit is ready for use.

Preparing the newly installed SSD for use:

All new USB storage device need to be initialize, partition and formatted for the Operating System you are using before it can store data.

For Windows Operating System, use Disk Management and for OS X, use Disk Utility.

For detail instruction refer to the FAO

"How to preparing a New storage, Hard Drive, or SSD for for use with a system? " on our website support section at WWW.VANTECUSA.COM

NST-M2STS3-BK